



Status of Structural Analysis of Substrates and Film Growth Inputs for GaN Device Development Program

by Kevin Kirchner

ARL-TR-5427

January 2011

NOTICES

Disclaimers

The findings in this report are not to be construed as an official Department of the Army position unless so designated by other authorized documents.

Citation of manufacturer's or trade names does not constitute an official endorsement or approval of the use thereof.

Destroy this report when it is no longer needed. Do not return it to the originator.

Army Research Laboratory

Adelphi, MD 20783-1197

ARL-TR-5427

January 2011

Status of Structural Analysis of Substrates and Film Growth Inputs for GaN Device Development Program

Kevin Kirchner

Sensors and Electron Devices Directorate, ARL

REPORT DOCUMENTATION PAGE			Form Approved OMB No. 0704-0188		
<p>Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing the burden, to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports (0704-0188), 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to any penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.</p> <p>PLEASE DO NOT RETURN YOUR FORM TO THE ABOVE ADDRESS.</p>					
1. REPORT DATE (DD-MM-YYYY) January 2011		2. REPORT TYPE Interim		3. DATES COVERED (From - To)	
4. TITLE AND SUBTITLE Status of Structural Analysis of Substrates and Film Growth Inputs for GaN Device Development Program		5a. CONTRACT NUMBER			
		5b. GRANT NUMBER			
		5c. PROGRAM ELEMENT NUMBER			
6. AUTHOR(S) Kevin Kirchner		5d. PROJECT NUMBER			
		5e. TASK NUMBER			
		5f. WORK UNIT NUMBER			
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) U.S. Army Research Laboratory ATTN: RDRL-SED-E 2800 Powder Mill Road Adelphi, MD 20783-1197		8. PERFORMING ORGANIZATION REPORT NUMBER ARL-TR-5427			
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)		10. SPONSOR/MONITOR'S ACRONYM(S)			
		11. SPONSOR/MONITOR'S REPORT NUMBER(S)			
12. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release; distribution unlimited.					
13. SUPPLEMENTARY NOTES					
14. ABSTRACT <p>This report covers the x-ray diffraction crystallographic analysis of semiconductor wafers involved in our team's project to produce gallium nitride (GaN) wide bandgap devices. The wafers were examined for crystal quality by symmetric and asymmetric GaN scans for each quadrant of the 18 wafers. Data comparisons made include the figures of merit (FOM) for GaN substrates compared with those of GaN films grown on the substrates, and the homoepitaxial GaN films' FOMs compared with those from heteroepitaxial films. The analysis produced the best FOMs for GaN for our lab to date: 39" (arc seconds) symmetric and 58" asymmetric. The good homoepitaxial GaN film quality was ~3 to 8 times better than that of good heteroepitaxial films. The heteroepitaxial GaN film quality was shown to be suited for our experimental needs. At a 95% confidence level, we were able to show a bias between the quality of the wafer quadrants of the Hydride Vapor Phase epitaxially grown GaN substrates. The microstructural quality of the material inputs as measured by x-ray diffraction is currently on track to play its part in the development of novel GaN-based devices.</p>					
15. SUBJECT TERMS GaN, homoepitaxial, x-ray diffraction, micro structural analysis, GaN Device Program, Schottky Devices, HEMT, film					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT UU	18. NUMBER OF PAGES 36	19a. NAME OF RESPONSIBLE PERSON Kevin Kirchner
a. REPORT Unclassified	b. ABSTRACT Unclassified	c. THIS PAGE Unclassified			19b. TELEPHONE NUMBER (Include area code) (301) 394-0093

Contents

List of Figures	iv
List of Tables	iv
Acknowledgments	v
1. Introduction and Background	1
2. Kyma GaN Substrates	3
3. SUNY Heteroepitaxial GaN Films on Sapphire Substrates	11
4. GaN Substrates vs. GaN Films Grown On Them	16
5. Homoepitaxial vs. Heteroepitaxial GaN Films	18
6. Observations and Conclusions	21
Appendix. Statistical Bias between Kyma GaN Wafer Quadrants	23
List of Symbols, Abbreviations, and Acronyms	27
Distribution List	28

List of Figures

Figure 1. Ranking of Kyma's GaN substrates by x-ray diffraction.	4
Figure 2. Scans of the monolithic and faceted GaN peaks. The plots are of intensity vs. position.....	6
Figure 3. Overview of the x-ray scans of Kyma's GaN wafers.....	7
Figure 4. Kyma GaN substrates, FWHM vs. quadrant plots. The grouping shows data pattern A.....	8
Figure 5. Kyma GaN substrates plots, FWHM vs. quadrant. The grouping of the plots shows data pattern B. Sym scans are blue and asym are red.	9
Figure 6. Kyma GaN substrates, FWHM vs. quadrant plots. The grouping of x-ray plots shows data pattern C.	10
Figure 7. Ranking of SUNY GaN/sapphire samples using x-ray diffraction.	12
Figure 8. Graphical overview of SUNY heteroepitaxial GaN data. The sym scans are blue and the asym scans are red.....	13
Figure 9. SUNY GaN/sapphire heteroepitaxial films, showing grouping of x-ray plots by data pattern A. The sym scans are blue and the asym scans are red.	14
Figure 10. SUNY GaN/sapphire heteroepitaxial films, showing grouping of x-ray plots by data pattern B. The sym scans are blue and the asym scans are red.	15
Figure 11. Graphical comparison of Kyma GaN Substrates and the GaN films grown on them, FWHM vs. quadrant plots.....	17
Figure 12. Comparison of homoepitaxial and heteroepitaxial films using sym scans.....	19
Figure 13. Comparison of homoepitaxial and heteroepitaxial films using asym scans.....	20

List of Tables

Table 1. GaN substrates vs. GaN films grown on them.....	16
Table A-1. Two factor ANOVA without replication.....	24
Table A-2. Paired sample T- test for QI and QIII.....	25

Acknowledgments

I would like to acknowledge the members of my team: Dr. Ken Jones, Dr. Randy Tomkins, Dr. Tim Walsh, Mike Derenge, and Cuong Nguyen for their help, support, and collaboration throughout the year. Additional thanks go to Dr. Walsh for his help with the statistical analysis contained within this report.

INTENTIONALLY LEFT BLANK.

1. Introduction and Background

Solid-state devices based on gallium nitride (GaN) have the potential to have superior electronic properties. After the type of material used, the quality of that material is critical. However growing and processing better materials is a laborious and very expensive process. An extremely useful way of tracking the material improvement process is through the use of x-ray diffraction. The wavelengths of the x-rays used are dimensionally on the scale of the smallest component (unit cell) of the atom's long range order. It is because of this relationship that x-ray diffraction is able to tell us how repeatable a group of unit cells are with respect to their neighbors. The higher the degree of repeatability in a crystalline solid, the higher the quality. The x-ray diffraction unit of measure of a material's quality is the full width at half maximum (FWHM) value.

This report covers the crystallographic analysis, by x-ray diffraction, of 18 recent wafers involved in our team's project to produce GaN-based wide bandgap (WBG) devices. The substrate and film inputs for the project came from Kyma, Crystal Systems, Mike Derenge, and our State University of New York (SUNY) partners. Some additional enabling collaborations during this period were with Georgia Institute of Technology, Pennsylvania State University, and Sandia National Laboratory. The wafers were examined by symmetric (sym) GaN (002) and asymmetric (asym) GaN (102) scans for each of the sub regions of the 18 wafers.

Besides the analysis of the basic crystalline quality of the project's inputs, many comparisons were made. For example, the figures of merit (FOMs) for GaN substrates were compared with the FOMs of GaN films that were grown on those substrates. Some comparisons between different FOMs are given in terms of percentage of improvements. So for example, if sample A had a FWHM value of 100" (arc seconds) and sample B had a FWHM value of 60", that comparison could be expressed as there being a 40% improvement between sample A and B. Also, it is worth noting that smaller FWHM values indicate better crystalline quality of a material.

Heteroepitaxially grown GaN films are still, relatively speaking, immature; and homoepitaxial GaN films, and the GaN substrates that make their existence possible, have even shorter analysis baselines. Because of the small number of good GaN homoepitaxial films currently available to us, this report is somewhat interim in nature. That said, my work has uncovered many encouraging material attributes. For example, the x-ray work includes the best FWHM numbers that I have measured for the GaN (002) peak, 39". FWHM values correlate with lower defect densities, and lower defect densities have been shown to correlate with better device characteristics.

With new material systems there are always challenges. The asymmetric x-ray scans seem to have revealed in plane, material quality issues. Many of these problems are conjectured to be caused by small angle grain boundaries (SAGBs).^{*} SAGBs are thought to be formed by an amassing of line defects.

This work, besides documenting the overall quality of the material, also differentiates between multiple technologies, different material processing, and interactions between inputs. Additionally this work constitutes an initial investment in being able to make “before and after” comparisons in the future.

At this stage of the project, I am not sure of what and how patterns in the data will show up, so I employ a number of different methods of organizing the data in this report, i.e., graphical, chart form, grouping levels, and overlays. Each section of the report includes a short section-specific introduction.

This report contains six sections:

1. Introduction and Background
2. Kyma GaN substrates
3. SUNY heteroepitaxial GaN films
4. GaN substrates and film comparisons
5. Homoepitaxial vs. heteroepitaxial GaN films
6. Observations and Conclusions

^{*}Callister, W. D. *Material Science and Engineering An Introduction*, Fourth Edition, John Wiley & Sons: New York 1997, p.77.

2. Kyma GaN Substrates

Twelve of Kyma's novel hydride vapor phase epitaxy (HVPE) GaN substrates, enabling homoepitaxial growth of GaN films, were analyzed. For analytical purposes, the twelve 1x1 cm wafers were divided into a total of 48 quadrants (Cartesian coordinate nomenclature). Each plot and major chart entry is labeled with the sample number from which it came. The plot's abscissa values are the quadrant number from which the data was taken; the ordinates are the FWHM values.

Notes:

- The plots of the x-ray scans were grouped by similarities of pattern. Patterns varied from having both sym (GaN 002) and asym (GaN 102) scans matching their counterparts to only having one of the pairs possess some similarity. There were also a couple of mirror image pairings between scans.
- The sym scans contained the best GaN FWHM value (39") I have seen to date. The asym values ranged from decent to poor. Sample 15691 (figure 1) had the best symmetric scans, averaging 40" across the four quadrants of its wafer. Quadrant I, for both sym and asym scans, had the best results across all samples. This could be caused by an inhomogeneity in the wafer's growth conditions. If an examination of the growth conditions turned up a difference it could potentially mean a significant improvement in the quality of the sample output as a whole. To be sure, we ran a statistical analysis and there is a statistically significant bias between the wafer quarters across the wafers (see the appendix). A level of detail of the scans that is not made clear by either the charts or the plots is the effect of an amassing of material defects, which create what are called SAGBs (figure 2).

Ranking of Kyma's GaN Substrates by X-ray Diffraction

Kyma Substrates, Symmetric Scan (002), Units: Arc Seconds						Wafer Rank
Wafer #	QI*	QII	QIII	QIV	Row Ave	
6921	82	84	173	114	113	10
6942	56	61	54	54	56	2
7041	56	69	93	82	75	5
7286	76	119	130	69	99	8
8183	49	83	65	54	63	4
8184	74	70	132	69	86	6
8185	167	154	157	154	158	11
8186	58	60	66	57	60	Tie 3
8187	72	157	85	72	97	7
12932	100	101	104	120	106	9
15691	39	39	40	41	39.75	Best 1
15994	54	60	61	65	60	Tie 3

Averages	74	88	97	79
Quad Ranking	1st (Best)	3rd	4th	2nd

Kyma Substrates, Asymmetric Scan (102), Units: Arc Seconds						Wafer Rank
Wafer #	QI	QII	QIII	QIV	Row Ave	
6921	525+204	402+342	551+321	624+164	858	5
6942	700	1033	995	993	930	6
7041	830	1225	1279	843	1044	8
7286	823	1172	1344	962	1075	9
8183	414	484	426	402	431	2
8184	477	564	670	545	564	3
8185	356	372	355	364	361	Best 1
8186	967	1217	1202	946	1083	10
8187	1008	1385	1263	937	1149	11
12932	1094	1756	1727	1172	1437	12
15691	544	648	656	542	598	4
15994	930	1161	1123	881	1024	7


Averages	739	980	993	781
Quad Ranking	1st (Best)	3rd	4th	2nd

Figure 1. Ranking of Kyma's GaN substrates by x-ray diffraction.

In figure 1, the following apply:

- QI through QIV stand for the different wafer quadrants. They are in Cartesian coordinates

as follows:



- There are 96 data points over 48 sample regions across 12 wafers.
- The asymmetric rocking curves (RCs) of sample 692.1 consisted of two distinct regions. The FWHM for each are included.

- For row and column averages, it is the sum of the two values that are used for sample 692.1.
- The row averages are also the sample average.

In addition to the rankings shown in the charts, the following was observed:

- The sym scans show a remarkable improvement over the industry standard.
- Up to their point in the sample stream, samples 8183, 8184, and 8185 were the 2nd, 3rd, and 1st, respectively, in in-plane (parallel to surface to sample) crystal quality. With sample 8186, the quality changed abruptly. Interestingly, the rankings of the quadrants across all samples are the same for both the sym and asym scans.

Figure 2 shows four scans (A through D). Scans A and B, although having similar FWHM numbers, show the start of a move from a monolithic to a multifaceted “flat topped” peak. With their flat-topped multifaceted peaks, scans C and D show the progression of the effect due to a further increase in the density of the SAGB.

Figure 3 presents a thumbnail overview of the GaN substrate plots.

Figures 4–6 show the enlarged individual plots.

The data from these x-ray scans of freestanding GaN substrates provides the first sets of data that allow subsequent comparisons between substrates and films and a more complete analysis between homoepitaxial and heteroepitaxial film growth. Eventually, the information will be carried forward into the analysis space where the processing and performance of devices is analyzed.

Monolithic and Facetted GaN Peaks







Figure 2. Scans of the monolithic and facetted GaN peaks. The plots are of intensity vs. position.




Figure 3. Overview of the x-ray scans of Kyma's GaN wafers.

Kyma GaN Substrates FWHM VS. Quadrant

Grouping of X-ray Plots
By Data Patterns: A,B,C

(Sym scans are blue, asym are red.)





Figure 4. Kyma GaN substrates, FWHM vs. quadrant plots. The grouping shows data pattern A.

Note: The sym scans are blue and the asym scans are red.




Figure 5. Kyma GaN substrates plots, FWHM vs. quadrant. The grouping of the plots shows data pattern B. Sym scans are blue and asym are red.




Figure 6. Kyma GaN substrates, FWHM vs. quadrant plots. The grouping of x-ray plots shows data pattern C.

Note: The sym scans are blue and the asym scans are red.

3. SUNY Heteroepitaxial GaN Films on Sapphire Substrates

Sym and asym scans were taken of the heteroepitaxial GaN films that were grown on five 2" sapphire wafers by our partners at SUNY. There is one x-ray plot per wafer containing both sym and asym scans (figure 8). Groupings of x-ray scans were again made on the basis of plot similarities (figure 9 and 10). Sample 2093N1 is one-half of a 2" wafer, having Quads I and IV. The collected data is also presented in chart form (figure 7). The chart shows rankings of the wafers and the quadrants across all SUNY wafers. The best wafer in terms of sym x-ray scans is 2093N. There was a tie for the best sample in terms of the asym scans, between samples 2079 and 2088. The best quadrant across all the wafers, in sym terms is QII. The best in terms of the asym scan analysis across all wafers is QI.

Note: Samples 2080 and 2088 were grown to be high electron mobility transistors (HEMTs) structures while the remaining samples were prepared to be Schottky devices. This means that the GaN films on 2080 and 2088 are thinner than those on the remaining samples. In heteroepitaxial growth, thicker films often show better structural quality than thinner films. Therefore if the two HEMT samples have similar or slightly worst FOMs this still signifies films of good quality in my opinion. Overall, sample 2080 had the second best scan out of the five samples for both sym and asym scans, and sample 2088 was the third best for sym scans and was tied for first for asym scans. Therefore, the HEMT samples echo the Schottky data, i.e., all our SUNY samples are of good microstructural quality.

These x-ray scans of the heteroepitaxial films are part of my group's analysis and documentation of the input streams for our GaN Device Program. In this report additional analyses are presented, for example, I compare the Kyma homoepitaxial films with these heteroepitaxial films in section 4. Over time, as we learned the quality of the samples and our expectations for the project grew, we increased the number of scans from 8 scans per 2" sample to 32. Our team has been developing GaN Schottky diodes and HEMTs with segments of these wafers.

Microsoft Excel - SUNYdata5_10.xls

File Edit View Insert Format Tools Data Window Help

Arial 10 B I U

N44 =

	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
1	SUNY														
2	Ranking of GaN / Sapphire Samples Using X-ray Diffraction														
3															
4									Averages		Wafer Rank		Notes		
5		Wafer #		QI*	QII	QIII	QIV		Sym	Asym	Sym	Asym			
6		2079	Sym	313	302	335	342		323		4		8 data pts (dps), 4 & 4		
7			Asym	413	434	459	459			441		1a			
8															
9		2080	Sym	266	250	269	277		266		2				
10			Asym	411	432	472	462			444			2 8 dps, 4 & 4		
11															
12		2088	Sym	271	254	274	288		272		3		32 dps		
13			Asym	403	404	481	474			441		1b			
14															
15		2093N	Sym	230	222	230	243		231		1		32 dps		
16			Asym	437	453	459	450			450		3			
17															
18		2093N1	Sym	227			237		232				1/2 wafer, 16 data pts		
19			Asym	425			416			421			16 dps, 8&8		
20		Averages	Sym	261	206	222	277								
21			Asym	418	431	468	452								
22															
23		Quad Rank	Sym	3	1	2	4								
24			Asm	1	2	4	3								
25															
26		Notes													
27		* QI - QIV stands for quadrants, using Cartesian coordinates													
28		Table units are arc seconds													
29		Symmetric scan values were in the good to excellent range													
30		Asymmetric peaks also showed v. good FOM, had a narrow range, and the peaks were monolithic													
31		Different sampling strategies over time made for inefficient use of data													
32		Top half of wafers were slightly better than the bottom half.													
33		Left side of samples ~ 25% better than right half for sym scans. Very close for asym peaks, slight advantage R side													
34															

Sheet1 / Sheet2 / Sheet3 /

Draw AutoShapes

Figure 7. Ranking of SUNY GaN/sapphire samples using x-ray diffraction. 12




Figure 8. Graphical overview of SUNY heteroepitaxial GaN data. The sym scans are blue and the asym scans are red.

SUNY GaN / Sapphire Heteroepitaxial Films

Grouping of X-ray Plots
By Data Patterns, A & B
(Sym scans are blue, asym are red)






Figure 9. SUNY GaN/sapphire heteroepitaxial films, showing grouping of x-ray plots by data pattern A. The sym scans are blue and the asym scans are red.




Figure 10. SUNY GaN/sapphire heteroepitaxial films, showing grouping of x-ray plots by data pattern B. The sym scans are blue and the asym scans are red.

4. GaN Substrates vs. GaN Films Grown On Them

This section presents a comparison of the structural quality of HVPE-grown GaN substrates and the metalorganic chemical vapor phase deposition (MOCVD) grown homoepitaxial GaN films produced on them. The data is represented in both table (table 1) and graphic (figure 11) forms. The following summary provides an additional examination of the data:

- The graphical output highlights the relationship between the substrates and films.
- The sym substrate and film scans track each other for both samples, but for the asym scans, they do not track for either sample.
- The sym values for both substrate and film of sample 8183 are excellent (table 1).
- The film values for the asym scans of 8184 contain an extraordinary value of 58”.
- The asym scans for the films are significantly lower than the substrate values, particularly for sample 8184.

These were the only homoepitaxial GaN films measured to date until a couple of weeks ago. Since then we have received a few samples from Lumilog/SUNY; however, they are not up to the level of quality of the Kyma samples examined here. The Lumilog/SUNY film’s sym values averaged ~200” and the film’s asym values averaged ~400”.

Table 1. GaN substrates vs. GaN films grown on them.

SAMPLE 8183	SAMPLE 8184
Sym Scan Values	Sym Scan Values
Substrate: 49, 83, 65, 54 Film : 50, 89, 66, 53	Substrate: 74, 70, 132, 69 Film : 69, 62, 109, 59
Notes	
Note: Very close match between substrate and film average values Sub 63”, Film 65”	Note: Similar average values, substrate and film: Sub 86”, Film 75”.
Asym Scan Values	Asym Scan Values
Substrate: 414, 484, 462, 402 Film : 268, 276, 291, 283	Substrate: 477, 564, 670, 545 Film : 58, 106, 86, 71
Notes	
Epi film numbers are 37% better than the substrate. Film 280” and Substrate 441”.	Substrate has values similar to 8183. Asym film values are very good, including a remarkable value of 58”. As a dataset, they are much better than the substrate’s asym values.




Figure 11. Graphical comparison of Kyma GaN Substrates and the GaN films grown on them, FWHM vs. quadrant plots


5. Homoepitaxial vs. Heteroepitaxial GaN Films

Two plots (sym and asym) containing eight scans were used to compare the homoepitaxial film data with the very good quality heteroepitaxial films we received, primarily, from our SUNY partners. Our team's principle grower, Mike Derenge, grew the homoepitaxial and heteroepitaxial films on the Kyma and the Crystal System's substrates, respectfully. All the SUNY and our principal grower's films were grown by MOCVD.

The comparisons for the sym scans show the homoepitaxial films improving over their heteroepitaxial counterparts by from 73% to 77% (figures 12 and 13). For the asym scans, the homoepitaxial films improved over their heteroepitaxial films by from 42% to 94%. It is very promising having two sym homoepitaxial FWHM values in the 50s, having an asym value in the 50s is extraordinary (i.e., sample 8184's 94% improvement). Good FWHM values correlate with lower defect densities, and lower defect densities are thought by the technical community to correlate with better device characteristics.

The homoepitaxial films show some remarkable improvements in crystal quality, unfortunately the devices that were fabricated on them had some performance issues. However, we do have initial data pointing to a solution for the device performance problems. Our group is currently in the process of implementing that solution.

Homoepitaxial (Red & Green) vs. Heteroepitaxial (Black & Blue) GaN Films **Sym FOM:** Crystal Systems (742), SUNY (2093), Kyma (8183A), Kyma (8184)



GaN films on Kyma and Crystal System substrates were grown by Mike Derenge, SUNY film was grown at SUNY

Figure 12. Comparison of homoepitaxial and heteroepitaxial films using sym scans.




Figure 13. Comparison of homoepitaxial and heteroepitaxial films using asym scans.

6. Observations and Conclusions

In this interim report, I have presented the results of the microstructural analysis using x-ray diffraction of substrate and film inputs to the GaN WBG Device Program of the Power Components Branch.

We have observed the following:

- Our best GaN (002) FWHM value to date 39". This is important because good FWHM numbers correlate with lower defect densities and lower defect densities are thought by the technical community to correlate with better device characteristics.
- We documented the quality of Kyma's novel HVPE GaN substrates by wafer and wafer quarters (figures 1, 4, 5, and 6).
- We provided a composite thumbnail overview of the sample plots of Kyma's novel GaN substrates (figure 3).
- We showed an example of the effect of peak broadening in x-ray output by SAGB (figure 2).
- Asym scans of 12 HVPE GaN substrate wafers show a broad range of FWHM values, ~350" to 1750" (figure 1).
- We had excellent asymmetric scan results of the homoepitaxial films (sample 8184) with FWHM values of 58" to 106" (table 1).
- We documented the good input quality of SUNY's heteroepitaxial films by wafer and wafer quarters (figure 7).
- The composite thumbnail plots of SUNY scans provided an overview of heteroepitaxial film's sym and asym scans to illustrate the relationships between them (figure 8).
- Homoepitaxial film quality showed improvement over the substrate it was grown on, in some cases by 5 to 7 times (Sample 8184, asym peaks, table 1).
- In sections 2, 3, and 4, we saw the variation in tracking between the sym and asym scans.
- We presented graphical comparisons between good quality GaN heteroepitaxial films and novel GaN homoepitaxial films from Kyma (figures 12 and 13).
- Kyma substrates' micro-structural quality showed a bias across their 12 wafers in favor of quadrants I and IV (figure 1 and tables A-1 and A-2). This could be useful information for our Kyma partners.

There has been a steep learning curve in our team, and the technical community at large, regarding GaN quality. Recently, we have also obtained data suggesting we are overcoming a major hurdle involving carbon's negative role in the low-doped GaN films, which we use in fabricating some of our devices.

As we are able to obtain additional good homoepitaxial films to use for device fabrication, and our fabrication techniques and understanding matures, there will likely be additional useful and instructive correlations.

One group in the GaN device community has recently, after five years of hard work, achieved the technical community's target 600-V breakdown voltage. We have also attained 600-V breakdown on Kyma substrates and we are working to duplicate these results in our films.

While x-ray diffraction can help us rate our material input streams, it can also help inform us about issues like the material imperfections behind the material consistency issues we are working through. Going forward using x-ray diffraction along with scanning electron microscopy (SEM), Atomic Force Microscopy (AFM), cathodoluminescence (CL), and etch pit techniques, we will try to better understand and control the number and types of material defects in our devices to a degree that will help us have good device yields.

Appendix. Statistical Bias between Kyma GaN Wafer Quadrants

The present data was examined to determine if the findings present in the report are statistically significant. Specifically, our goal was to determine if the mean FWHMs of the 002 (symmetric) reflections differed between quadrants of the Kyma samples. Two separate analyses were undertaken. First, the four quadrants were compared with the use of a two-factor analysis of variance (ANOVA). Second, the quadrants with the largest difference in mean, QI and QIII, were compared with a paired sample T-test.

The ANOVA analysis comparing the four quadrants is shown on table A-1. The 002 FWHM data are contained in the top table and are organized by wafer (row) and quadrant (column). Below the FWHM data is a tabulation of statistics on the individual columns (quadrants) which are used in the ANOVA calculation. For each column, the sum (T_a), sum squared (T_a^2), number of observations (n_a), mean, and standard deviation are calculated. Likewise, statistics are calculated by row (wafer) and tabulated to the right of the main data table. Below the table, the calculation steps are outlined, including calculation of the grand total T and total number of observations n . Sum of squares variation due to factor A (that is, due to variation by column, or equivalently by quadrant of the wafer) SS_A is calculated, along with the mean square variation due to factor A, MS_A . Likewise, the sum of squares and mean square variation SS_B and MS_B are calculated for variation due to factor B (that is, variation by row, or equivalently by wafer). The sum of squares due to interaction between the two factors SS_{AB} is shown, along with the mean square variation MS_{AB} (also known as error variance). Finally, the total sum of squares is given. Below these, the F value is given for variation due to factor A (data column or quadrant) and factor B (data row or wafer). The F value is given by $F_x = MS_x/MS_{AB}$, where x is A or B. Next to the F value for both factors, the probability (from the F distribution) is given. The probability P_A for factor A is interpreted as the probability that the four columns share the same mean. The value is 0.053, or equivalently there is a $1 - P_A = 0.947$ probability that the four columns (quadrants) do not have the same mean. Thus we have rigorously shown that there is a statistically significant difference in the mean value of the 002 FWHM depending on the quadrant of the wafer for these Kyma wafers.

Table A-1. Two factor ANOVA without replication.

Two factor ANOVA without replication										
Wafer #	QI	QII	QIII	QIV	T _b	T _b ²	n _b	Mean	Std. dev	
6921	82	84	173	114	453	205209	4	113.25	42.44	
6942	56	61	54	54	225	50625	4	56.25	3.30	
7041	56	69	93	82	300	90000	4	75.00	16.02	
7286	76	119	130	69	394	155236	4	98.50	30.49	
8183	49	83	65	54	251	63001	4	62.75	15.06	
8184	74	70	132	69	345	119025	4	86.25	30.58	
8185	167	154	157	154	632	399424	4	158.00	6.16	
8186	58	60	66	57	241	58081	4	60.25	4.03	
8187	72	157	85	72	386	148996	4	96.50	40.80	
12932	100	101	104	120	425	180625	4	106.25	9.32	
15691	39	39	40	41	159	25281	4	39.75	0.96	
15994	54	60	61	65	240	57600	4	60.00	4.55	
T _a	883	1057	1160	951						
T _a ²	779689	1117249	1345600	904401						
n _a	12	12	12	12						
Mean	73.583	88.083	96.667	79.250						
Std. dev	33.776	37.744	42.934	33.251						
T	4051	Grand total								
n	48	Total number of observations								
SS _A	3690.7	Sum of squares variation due to factor A (by column)								
MS _A	1230.2	Mean square variation due to factor A (by column)								
SS _B	46388.2	Sum of squares variation due to factor B (by row)								
MS _B	4217.1	Mean square variation due to factor B (by column)								
SS _{AB}	14270.5	Interaction sum of squares								
MS _{AB}	432.4	Interaction mean square variation (also called error variance)								
SS _{total}	64349.5	Total sum of squares								
	F	P								
A (column)	2.845	0.053	P is the probability that the different columns share the same mean							
B (row)	9.752	1E-07								
F	2.845	F statistic for variation between columns (quadrants)								
P	0.053	Probability that different quadrants have same mean								
P	0.947	Probability that different quadrants are statistically different (ie they do not have the same mean)								

Table A-2 shows the T-test analysis. The two quadrants were chosen because they have the largest difference in mean value, 73.58 (QI) compared with 96.67 (QIII). The table shows the 002 FWHMs organized by wafer (row) and quadrant (column). To the right of the FWHM data, the mean for each row is given, as well as the difference d between the QI and QIII values for

each wafer. Below the table, statistics are calculated for each column (quadrant), including the mean, standard deviation, variance, and total number of observations n . The test statistic t is given by

$$t = \frac{d_{avg}}{s_d / \sqrt{n}} \quad (\text{A.1})$$

where d_{avg} is the average difference between QI and QIII, s_d is the standard deviation of the difference, and n is the number of observations. From the test statistic, the t-distribution yields a probability of 0.024 that the two samples (quadrants I and III) have the same mean, that is, there is a 97.6% chance that they come from populations with different means. Thus, we can rigorously conclude that there is a significant difference in the means of the 002 FWHMs for quadrants I and III in the Kyma-grown GaN samples. Furthermore, from the t value corresponding to a probability of 0.05, the 95% confidence interval for the mean difference between QI and QIII is found to be 19.34. Thus, we can say at a 95% confidence level that the difference between the mean values of QI and QIII is 23.08 ± 19.34 . Further testing should help to narrow down the confidence window allowing us to more precisely determine the mean difference between the 002 FWHM of QI and QIII.

Table A-2. Paired sample T- test for QI and QIII.

Paired sample T-test for QI and QIII						
Wafer #	QI*	QII	QIII	QIV	Mean	d (QI - QIII)
6921	82	84	173	114	113.25	-91
6942	56	61	54	54	56.25	2
7041	56	69	93	82	75.00	-37
7286	76	119	130	69	98.50	-54
8183	49	83	65	54	62.75	-16
8184	74	70	132	69	86.25	-58
8185	167	154	157	154	158.00	10
8186	58	60	66	57	60.25	-8
8187	72	157	85	72	96.50	-13
12932	100	101	104	120	106.25	-4
15691	39	39	40	41	39.75	-1
15994	54	60	61	65	60.00	-7
Mean:	73.583	88.083	96.667	79.250		-23.083
Standard dev:	33.776	37.744	42.934	33.251		30.444
Variance:	1140.811	1424.629	1843.333	1105.659		926.81
n:	12	12	12	12		12

Paired test, two tailed	
-2.627	Test statistic
0.024	Probability the two samples have the same mean
0.976	Probability the two samples do not have the same mean
Mean difference:	-23.083
95% confidence interval:	19.343

INTENTIONALLY LEFT BLANK.

List of Symbols, Abbreviations, and Acronyms

ANOVA	analysis of variance
Asym	asymmetric x-ray scan
CL	cathodoluminescence
FOM	figure of merit
FWHM	full width at half maximum
GaN	gallium nitride
HEMT	high electron mobility transistors
HVPE	hydride vapor phase epitaxy
MOCVD	metalorganic chemical vapor phase deposition
SAGB	small angle grain boundary
SEM	scanning electron microscopy
SUNY	State University of NY
Sym	symmetric x-ray scan
WBG	wide bandgap

No. of

Copies Organization

1 ELEC	ADMNSTR DEFNS TECHL INFO CTR ATTN DTIC OCP 8725 JOHN J KINGMAN RD STE 0944 FT BELVOIR VA 22060-6218
1 HC	US ARMY RSRCH LAB ATTN RDRL CIM G T LANDFRIED BLDG 4600 ABERDEEN PROVING GROUND MD 21005-5066
3 HCS	US ARMY RSRCH LAB ATTN IMNE ALC HRR MAIL & RECORDS MGMT ATTN RDRL CIM L TECHL LIB ATTN RDRL CIM P TECHL PUB ADELPHI MD 20783-1197
10 HCS 1 CD	US ARMY RSRCH LAB ATTN RDRL SED ED SHAFFER ATTN RDRL SED E BRUCE GEIL PAUL BARNES KEN A JONES TIM WALSH RANDY TOMPKINS CUONG NGUYEN KEVIN KIRCHNER (1 CD, 3 HCS)

TOTAL: 16 (1 ELEC, 1 CD, 14 HCS)